



LAB-3

IMU


Stationary Noise Analysis

- Orientation Plots




The mean and standard deviation of yaw is $(-0.8927, 0.0049)$, pitch is $(-1.0547, 0.0053)$ and roll is $(-2.8221, 0.0951)$. The noise distribution of yaw and pitch are normal but that of roll is unevenly distributed, bimodal.

- Angular Velocity Plots




The mean and standard deviation of angular velocity x is (2.1834×10^{-5} , 7.0210×10^{-4}), angular velocity y is (-3.0297×10^{-6} , 7.8932×10^{-4}) and angular velocity z is (-1.1413×10^{-6} , 7.0091×10^{-4}). The noise distribution of the angular velocity along all axes is normal as it fits inside the gaussian bell curve.

- Linear Acceleration Plots



The mean and standard deviation of linear acceleration x is (-0.7212, 0.0126), linear acceleration y is (-0.1529, 0.0121) and linear acceleration z is (-9.8301, 0.0182). The noise distribution of the linear acceleration along all axes is normal distribution.

- Magnetic Field Plots



The mean and standard deviation of magnetic field x is (0.3640, 0.0016), magnetic field y is (0.1169, 0.0034) and magnetic field z is (0.3720, 0.0048). The noise is unevenly distributed.

Allan Variance (5 hour)

Allan Variance is a time domain analysis technique designed for characterizing noise and stability. The technique can be applied to any signal to determine the character of the underlying noise processes. The Allan Variance of a signal is a function of averaging time.



It helps us understand how the precision of a sensor changes as we average the measurements over different time spans.



For our IMU, the important processes that we should measure are random walk, noise density and in run bias stability.

Bias stability is a measure of the long-term stability or drift in the output of an inertial sensor. It quantifies how the bias (or offset) of the sensor's readings changes over time.

| IMU Specifications | ACCELEROMETER | GYROSCOPE | MAGNETOMETER |
|--|----------------------|-------------------------|---------------------|
| Range | ±16 g | ±2,000°/s | ±2.5 Gauss |
| In-Run Bias Stability (Allan Variance) | < 0.04 mg | < 10°/hr (5-7°/hr typ.) | - |
| Noise Density | 0.14 mg/√Hz | 0.0035 °/s /√Hz | 140 μGauss/√Hz |
| Bandwidth | 260 Hz | 256 Hz | 200 Hz |
| Cross-Axis Sensitivity | ±0.05 ° | < 0.05 ° | ±0.05 ° |

The bias stability of VN 100 is mentioned above.





The sources of error are disturbance due to vibrations in the surroundings, noisy environment, bias error, scale factor ,installation error and random noise.

